USQ# TF-07-1077-S

CH2M HILL Hanford Group, Inc.	Manual	ESHQ
	Document	TFC-ESHQ-FP-STD-04, REV A-5
FIRE PROTECTION SYSTEM	Page	1 of 20
TESTING, INSPECTION, AND	Issue Date	July 10, 2007
MAINTENANCE	Effective Date	July 10, 2007

Ownership matrix

TABLE OF CONTENTS

1.0	PURI	POSE AND SCOPE	2
2.0			
3.0	STA	NDARD	2
4.0	DEFI	INITIONS	2
5.0		RCES	
	5.1	Requirements	
	5.2	•	
Tab	le 1. Alar	TABLE OF TABLES m System Testing/Inspection and Maintenance	3
		pression System Testing/Inspection and Maintenance	
		cellaneous System Testing/Inspection and Maintenance	
		TABLE OF ATTACHMENTS	
ATT	ГАСНМЕ	NT A – RECALL FREQUENCY PROTOCOL	20

MAINTENANCE

1.0 PURPOSE AND SCOPE

(5.1.1, 5.1.2)

This standard provides the minimum requirements for fire protection system testing, inspection, and maintenance in government-owned facilities under the CH2M HILL Hanford Group, Inc. (CH2M HILL) contract.

Although support in achieving the requirements of this section is provided by the Hanford Fire Department, the final responsibility for ensuring full compliance with this section shall belong to the facility management. This standard establishes the minimum operability specifications for fire protection features in TFC facilities. Compliance with the inspection and testing requirements will provide the required assurance that the systems are available and reliable.

2.0 **IMPLEMENTATION**

This standard is effective on the date shown in the header.

3.0 **STANDARD**

All fire protection systems (including those identified in facility technical specifications or similar documents) shall be, at a minimum, inspected, tested, and maintained in accordance with the requirements described in the tables in this standard. Management shall provide all necessary support for the inspection, testing, and maintenance of fire protection systems.

NOTE: The building manager is responsible for completing the inspection/testing activities identified in the following tables with an asterisk (*) in the device column. All other activities are scheduled and performed by the Hanford Fire Department.

All inspection, testing, and maintenance conducted on fire protection systems shall be performed by trained personnel in accordance with Hanford Fire Department internal procedures.

DEFINITIONS 4.0

No terms or phrases unique to this standard are used.

5.0 **SOURCES**

5.1 Requirements

- 1. DOE O 420.1A, "Fire Protection." (S/RID)
- 2. ORP M 420.1-1, "ORP Fire Protection Program." (S/RID)

5.2 References

TFC-BSM-FPM PR-C-11, "Winterization Plan for 200 Area Tank Farm Facilities." cuments external to this procedure are required for performance.

ESHQ	Document	TFC-ESHQ-FP-STD-04, REV A-5
	Page	3 of 20
FIRE PROTECTION SYSTEM TESTING, INSPECTION, AND	Effective Date	July 10, 2007
MAINTENANCE		

Table 1. Alarm System Testing/Inspection and Maintenance.

Control Panels

light emitting diodes (LEDs) 2. Fuses ATP & Annually: Remove any unlacquered fuses and verify they are the correct style and rating. Verify the appropriate supervisory signals are received. Apply inspector's lacquer. Inspect visible fuses for untampered lacquer. 3. Circuit Interface Verification Annually: Initiate an alarm condition for each initiation circuit or zone. Verify the signal is transmitted to the computer-aided dispatch system. Annually: Place at least one zone into alarm when bells are ringing. Verify zone transmission to HFD. 4. Audible and Visible Trouble Signal Signal Signal Annually: Werify operation of panel trouble signals and ring-back feature for systems using a trouble silencing switch which requires resetting. Annually: When control unit (panel) has zone disconnect or bypass switches, verify each switch performs the intended function and a trouble signal is received when a zone is disconnected. Annually: If system has ground detection feature, verify a ground-fault indication is given whenever any installation conductor is grounded. 7-3.2 Tables 7-2.2, 7-3.1	1	B 11	1	NIED 1 50
diodes (LEDs) indications. 2. Fuses ATP & Annually: Remove any unlacquered fuses and verify they are the correct style and rating. Verify the appropriate supervisory signals are received. Apply inspector's lacquer. Inspect visible fuses for untampered lacquer. 3. Circuit Interface Verification Annually: Initiate an alarm condition for each initiation circuit or zone. Verify the signal is transmitted to the computer-aided dispatch system. Annually: Place at least one zone into alarm when bells are ringing. Verify zone transmission to HFD. 4. Audible and Visible Trouble Signal visible Trouble Signal silencing switch which requires resetting. 5. Bypass Disconnect Switches Disconnect Switches Performs the intended function and a trouble signal is received when a zone is disconnected. 6. Ground-Fault Monitoring Circuit 7. Power Supply Monitoring Circuits ATPA 7.3.2 ATBLES 7-2.2, 7-3.1 Tables 7-2.2, 7-3.1	1.	Panel lamps,	Annually: Verify all illuminating devices have the	NFPA 72;
2. Fuses ATP & Annually: Remove any unlacquered fuses and verify they are the correct style and rating. Verify the appropriate supervisory signals are received. Apply inspector's lacquer. Inspect visible fuses for untampered lacquer. 3. Circuit Interface Verification Annually: Initiate an alarm condition for each initiation circuit or zone. Verify the signal is transmitted to the computer-aided dispatch system. 4. Audible and Visible Trouble Signal Signal Verify operation of panel trouble signals and ring-back feature for systems using a trouble silencing switch which requires resetting. 5. Bypass Annually: When control unit (panel) has zone disconnect Switches performs the intended function and a trouble signal is received when a zone is disconnected. 6. Ground-Fault Monitoring Circuit Annually: If system has grounded. 7. Power Supply Monitoring Circuits Public Annually: Verify proper supervision for both primary and secondary power supplies. Verify Tables 7-2.2, 7-3.1 Tables 7-2.2, 7-				_ ·
and verify they are the correct style and rating. Verify the appropriate supervisory signals are received. Apply inspector's lacquer. Inspect visible fuses for untampered lacquer. 3. Circuit Interface Verification Annually: Initiate an alarm condition for each initiation circuit or zone. Verify the signal is transmitted to the computer-aided dispatch system. Annually: Place at least one zone into alarm when bells are ringing. Verify zone transmission to HFD. Annually: Verify operation of panel trouble signals and ring-back feature for systems using a trouble silencing switch which requires resetting. Bypass Disconnect Switches Discon		diodes (LEDs)		
Verify the appropriate supervisory signals are received. Apply inspector's lacquer. Inspect visible fuses for untampered lacquer. 3. Circuit Interface Verification Annually: Initiate an alarm condition for each initiation circuit or zone. Verify the signal is transmitted to the computer-aided dispatch system. Annually: Place at least one zone into alarm when bells are ringing. Verify zone transmission to HFD. 4. Audible and Visible Trouble Signal and ring-back feature for systems using a trouble silencing switch which requires resetting. 5. Bypass Annually: When control unit (panel) has zone disconnect or bypass switches, verify each switch performs the intended function and a trouble signal is received when a zone is disconnected. 6. Ground-Fault Monitoring Circuit 7. Power Supply Monitoring Circuits Annually: Verify proper supervision for both primary and secondary power supplies. Verify Monitoring Circuits battery transfer and charging features. Operate 7. Tables 7-2.2, 7-3.1 Tab	2.	Fuses		I
received. Apply inspector's lacquer. Inspect visible fuses for untampered lacquer. 3. Circuit Interface Verification Annually: Initiate an alarm condition for each initiation circuit or zone. Verify the signal is transmitted to the computer-aided dispatch system. Annually: Place at least one zone into alarm when bells are ringing. Verify zone transmission to HFD. 4. Audible and Visible Trouble Signal Signal Silencing switch which requires resetting. 5. Bypass Disconnect Switches Disconnect Switches Disconnect Switches Disconnect Annually: When control unit (panel) has zone disconnect or bypass switches, verify each switch performs the intended function and a trouble signal is received when a zone is disconnected. Annually: If system has ground detection feature, verify a ground-fault indication is given whenever any installation conductor is grounded. 7-3.2 Annually: Verify proper supervision for both primary and secondary power supplies. Verify Tables 7-2.2, 7-3.1 Tables 7			, , ,	Tables 7-2.2, 7-3.1, &
fuses for untampered lacquer. 3. Circuit Interface Verification Annually: Initiate an alarm condition for each initiation circuit or zone. Verify the signal is transmitted to the computer-aided dispatch system. Annually: Place at least one zone into alarm when bells are ringing. Verify zone transmission to HFD. 4. Audible and Visible Trouble Signal Signal Signal Annually: Verify operation of panel trouble signals and ring-back feature for systems using a trouble silencing switch which requires resetting. Annually: When control unit (panel) has zone disconnect or bypass switches, verify each switch performs the intended function and a trouble signal is received when a zone is disconnected. Ground-Fault Monitoring Circuit Annually: If system has ground detection feature, verify a ground-fault indication is given whenever any installation conductor is grounded. Annually: Verify proper supervision for both primary and secondary power supplies. Verify Tables 7-2.2, 7-3.1 Tables 7-2.2,				7-3.2
Circuit Interface Verification Annually: Initiate an alarm condition for each initiation circuit or zone. Verify the signal is transmitted to the computer-aided dispatch system. Tables 7-2.2, 7-3.1				
Verification initiation circuit or zone. Verify the signal is transmitted to the computer-aided dispatch system. Annually: Place at least one zone into alarm when bells are ringing. Verify zone transmission to HFD. 4. Audible and Visible Trouble Signal Visible Trouble Signal silencing switch which requires resetting. 5. Bypass Annually: When control unit (panel) has zone disconnect or bypass switches, verify each switch performs the intended function and a trouble signal is received when a zone is disconnected. 6. Ground-Fault Monitoring Circuit Annually: Verify proper supervision for both primary and secondary power supplies. Verify Tables 7-2.2, 7-3.1			fuses for untampered lacquer.	
transmitted to the computer-aided dispatch system. Annually: Place at least one zone into alarm when bells are ringing. Verify zone transmission to HFD. 4. Audible and Visible Trouble Signal visible Trouble Signal silencing switch which requires resetting. 5. Bypass Annually: When control unit (panel) has zone disconnect or bypass switches, verify each switch performs the intended function and a trouble signal is received when a zone is disconnected. 6. Ground-Fault Monitoring Circuit 7-3.2 Annually: If system has ground detection feature, verify a ground-fault indication is given whenever any installation conductor is grounded. Annually: Verify proper supervision for both primary and secondary power supplies. Verify Tables 7-2.2, 7-3.1 battery transfer and charging features. Operate 7-3.2 Tables 7-2.2, 7-3.1 NFPA 72; Tables 7-2.2, 7-3.1 NFPA 72; Tables 7-2.2, 7-3.1 NFPA 72; Tables 7-2.2, 7-3.1	3.	Circuit Interface		NFPA 72;
Annually: Place at least one zone into alarm when bells are ringing. Verify zone transmission to HFD. 4. Audible and Visible Trouble Signal visible Trouble Signal silencing switch which requires resetting. 5. Bypass Disconnect Switches Performs the intended function and a trouble signal is received when a zone is disconnected. 6. Ground-Fault Monitoring Circuit Annually: If system has ground detection feature, verify a ground-fault indication is given whenever any installation conductor is grounded. 7. Power Supply Monitoring Circuits battery transfer and charging features. Operate NFPA 72; Tables 7-2.2, 7-3.1 Tabl		Verification	initiation circuit or zone. Verify the signal is	Tables 7-2.2, 7-3.1, &
bells are ringing. Verify zone transmission to HFD. 4. Audible and Visible Trouble Signal Visible Trouble Signal Silencing switch which requires resetting. 5. Bypass Annually: When control unit (panel) has zone disconnect or bypass switches, verify each switch performs the intended function and a trouble signal is received when a zone is disconnected. 6. Ground-Fault Monitoring Circuit Annually: If system has ground detection feature, verify a ground-fault indication is given whenever any installation conductor is grounded. 7. Power Supply Monitoring Circuits Annually: Verify proper supervision for both Monitoring Circuits battery transfer and charging features. Operate Tables 7-2.2, 7-3.1 Tab			transmitted to the computer-aided dispatch system.	7-3.2
bells are ringing. Verify zone transmission to HFD. 4. Audible and Visible Trouble Signal Visible Trouble Signal Silencing switch which requires resetting. 5. Bypass Annually: When control unit (panel) has zone disconnect or bypass switches, verify each switch performs the intended function and a trouble signal is received when a zone is disconnected. 6. Ground-Fault Monitoring Circuit Annually: If system has ground detection feature, verify a ground-fault indication is given whenever any installation conductor is grounded. 7. Power Supply Monitoring Circuits battery transfer and charging features. Operate Disconter transmission to HFD. NFPA 72; Tables 7-2.2, 7-3.1				
4. Audible and Visible Trouble Signal and ring-back feature for systems using a trouble signal silencing switch which requires resetting. 5. Bypass Disconnect Disconnect Switches Performs the intended function and a trouble signal is received when a zone is disconnected. 6. Ground-Fault Monitoring Circuit Annually: Verify proper supervision for both Monitoring Circuits Date of Circuit Switch Suttery transfer and charging features. Operate NFPA 72; Tables 7-2.2, 7-3.1 NFPA 7				
Visible Trouble Signal and ring-back feature for systems using a trouble silencing switch which requires resetting. 5. Bypass Disconnect Switches Disconnect Switch Switches Disconnect Switch Switches Disconnect Switch Switch Switches Disconnect Switch Switch Switches Disconnect Switch Swi			bells are ringing. Verify zone transmission to HFD.	
Signal silencing switch which requires resetting. 5. Bypass Annually: When control unit (panel) has zone disconnect or bypass switches, verify each switch performs the intended function and a trouble signal is received when a zone is disconnected. 6. Ground-Fault Monitoring Circuit any installation conductor is grounded. 7-3.2 Annually: If system has ground detection feature, verify a ground-fault indication is given whenever any installation conductor is grounded. 7-3.2 Annually: Verify proper supervision for both Monitoring Circuits battery transfer and charging features. Operate 7-3.2 7-3.2 NFPA 72; Tables 7-2.2, 7-3.1 NFPA 72; Tables 7-2.2, 7-3.1	4.	Audible and		NFPA 72;
5. Bypass Disconnect disconnect or bypass switches, verify each switch performs the intended function and a trouble signal is received when a zone is disconnected. 6. Ground-Fault Monitoring Circuit Annually: If system has ground detection feature, verify a ground-fault indication is given whenever any installation conductor is grounded. 7. Power Supply Monitoring Circuits Annually: Verify proper supervision for both primary and secondary power supplies. Verify Tables 7-2.2, 7-3.1 Tables 7-2.2, 7-3.		Visible Trouble		Tables 7-2.2, 7-3.1, &
Disconnect Switches disconnect or bypass switches, verify each switch performs the intended function and a trouble signal is received when a zone is disconnected. 6. Ground-Fault Monitoring Circuit 7. Power Supply Monitoring Circuits Annually: If system has ground detection feature, verify a ground-fault indication is given whenever any installation conductor is grounded. Annually: Verify proper supervision for both primary and secondary power supplies. Verify battery transfer and charging features. Operate Tables 7-2.2, 7-3.1		Signal	silencing switch which requires resetting.	7-3.2
Switches performs the intended function and a trouble signal is received when a zone is disconnected. 6. Ground-Fault Monitoring Circuit any installation conductor is grounded. 7-3.2 Annually: If system has ground detection feature, verify a ground-fault indication is given whenever any installation conductor is grounded. 7-3.2 7. Power Supply Monitoring primary and secondary power supplies. Verify Detection for both primary and secondary power supplies. Verify Tables 7-2.2, 7-3.1 Circuits battery transfer and charging features. Operate	5.	Bypass	Annually: When control unit (panel) has zone	NFPA 72;
is received when a zone is disconnected. 6. Ground-Fault Monitoring Circuit 7. Power Supply Monitoring Monitoring Circuits Annually: Verify proper supervision for both Primary and secondary power supplies. Verify Tables 7-2.2, 7-3.1 Tables 7-2		Disconnect	disconnect or bypass switches, verify each switch	Tables 7-2.2, 7-3.1, &
6. Ground-Fault Monitoring Circuit Annually: If system has ground detection feature, verify a ground-fault indication is given whenever any installation conductor is grounded. 7. Power Supply Monitoring Circuits Annually: Verify proper supervision for both primary and secondary power supplies. Verify Tables 7-2.2, 7-3.1 Tables 7-2.2, 7-3.2		Switches	performs the intended function and a trouble signal	7-3.2
Monitoring Circuit Power Supply Monitoring Circuits Verify a ground-fault indication is given whenever any installation conductor is grounded. 7-3.2 Annually: Verify proper supervision for both primary and secondary power supplies. Verify Tables 7-2.2, 7-3.1 Circuits Verify a ground-fault indication is given whenever any installation conductor is grounded. 7-3.2 NFPA 72; Tables 7-2.2, 7-3.1 Tables 7-2.2, 7-3.1 7-3.2			is received when a zone is disconnected.	
Circuit any installation conductor is grounded. 7-3.2 7. Power Supply Annually: Verify proper supervision for both Monitoring primary and secondary power supplies. Verify Circuits battery transfer and charging features. Operate 7-3.2	6.	Ground-Fault	Annually: If system has ground detection feature,	NFPA 72;
7. Power Supply Monitoring Circuits Annually: Verify proper supervision for both primary and secondary power supplies. Verify battery transfer and charging features. Operate NFPA 72; Tables 7-2.2, 7-3.1		Monitoring	verify a ground-fault indication is given whenever	Tables 7-2.2, 7-3.1, &
Monitoring primary and secondary power supplies. Verify Circuits battery transfer and charging features. Operate Tables 7-2.2, 7-3.1		Circuit	any installation conductor is grounded.	7-3.2
Circuits battery transfer and charging features. Operate 7-3.2	7.	Power Supply	Annually: Verify proper supervision for both	NFPA 72;
				Tables 7-2.2, 7-3.1, &
direct current bells and panel in an alarm condition		Circuits	battery transfer and charging features. Operate	7-3.2
			direct current bells and panel in an alarm condition	
for a minimum of 5 minutes on batteries.			for a minimum of 5 minutes on batteries.	
8. Nonrestorable Replace the detectors with restorable heat NFPA 72,	8.	Nonrestorable	Replace the detectors with restorable heat	NFPA 72,
Spot and Wire- detector(s) having the correct temperature rating. <u>Table 7-2.2, 13.d</u>		Spot and Wire-	detector(s) having the correct temperature rating.	Table 7-2.2, 13.d.3
Type Heat		Type Heat		
Detectors		Detectors		

ESHQ	Document	TFC-ESHQ-FP-STD-04, REV A-5
	Page	4 of 20
FIRE PROTECTION SYSTEM	Effective Date	July 10, 2007
TESTING, INSPECTION, AND MAINTENANCE		

Table 1. Alarm System Testing/Inspection and Maintenance. (cont.)

Control Panels

	9.	Restorable Heat	Annually: Inspect all detectors to ensure they are	NFPA 72;
		and Wire-Type	in good condition and there is nothing to impair	Tables 7-2.2, 7-3.1, &
		Detectors	proper operation. Test 20% a minimum of the two	7-3.2
			detectors on each initiating circuit each year, so all	
			detectors are tested every 5 years; at least one	
l			detector per zone must be tested annually.	
			Test detectors with one of the following, taking care	
			not to overheat and damage the detector and	
			surrounding environs.	
			• Use a heat gun or similar apparatus.	
			• Use the built-in heating coil (supplied with	
			the detector in some inaccessible areas).	
	10.	Smoke Detectors	Annually: Inspect all detectors to ensure they are	NFPA 72;
		(Ionization or	in good condition and there is nothing to impair	Tables 7-2.2, 7-3.1, &
		Photoelectric)	proper operation.	7-3.2
			Ensure each smoke detector is operative and	
			produces the intended response. Initiate an alarm at	
			the installed location with smoke or other aerosol	
			acceptable to the manufacturer.	
			For sampling air duct detector, verify the device will	
			sample the air stream in accordance with	
			manufacturer's instructions.	
			Semi-Annually: Inspect sampling air duct	
			detectors to ensure they are secure, not damaged,	
			and operational.	
	11.	Smoke Detectors	Biennially (5yrs if sensitivity is remaining	NFPA 72;
		(Ionization or Photoelectric)	stable): Perform a sensitivity check using	7-3.2.1
		Filotoelectric)	manufacturer approved testers or listed control panel equipment. Visually inspect all detectors in place,	
			wherever possible.	
			where yet possible.	
			Perform sensitivity check 1 year after new	
			installation and biennial thereafter.	
	12.	Flame/Radiant	Semiannually: Inspect all detectors to ensure they	NFPA 72;
		Energy	are in good condition and there is nothing to impair	Tables 7-2.2, 7-3.1, &
			proper operation. Perform a test using the	7-3.2
			equipment manufacturer recommended technique.	

ESHQ	Document	TFC-ESHQ-FP-STD-04, REV A-5
	Page	5 of 20
FIRE PROTECTION SYSTEM TESTING, INSPECTION, AND	Effective Date	July 10, 2007
MAINTENANCE		

Table 1. Alarm System Testing/Inspection and Maintenance. (cont.)

13.	Fire/Gas	Annually: Inspect all detectors to ensure they are	NFPA 72;
	Detector	in good condition and there is nothing to impair	Tables 7-2.2, 7-3.1, 8
		proper operation. Perform a test using the	7-3.2
		equipment manufacturer recommended technique.	
14.	Water Flow	Semiannually: Flow water through the inspector's	NFPA 72;
	Alarm (Flow or	test valve(s) or alarm test valve. Monitor the	Tables 7-2.2, 7-3.1, 6
	Pressure Switch)	response to ensure a fire alarm signal is generated	7-3.2
		at the facility fire alarm control panel within	NFPA 25, Table 5.1
		90 seconds and the local flow alarm sounds.	
15.	Extinguishing	Annually: Use the manufacturer's recommended	NFPA 72;
	Systems Alarm	technique to test the system. Send the extinguishing	Tables 7-2.2, 7-3.1, 6
	Initiation Switch	system into a fire alarm condition. Monitor the	7-3.2
	(Foam, Halon,	signal to ensure it will transmit to the Hanford Fire	
	dDry chemical,	Department.	
	CO₂, limited		
	water systems,		
	etc.)		
16.	Manual Stations	Annually: Actuate each manual station to verify	NFPA 72;
	(Pull Boxes)	the station transmits an alarm signal to the facility	Tables 7-2.2, 7-3.1, 6
		fire alarm control panel.	7-3.2
17.	Supervisory	Annually: Verify the alarm set point occurs only at	NFPA 72;
	Signal Initiating	the intended level and is within the limits specified	Tables 7-2.2, 7-3.1, 8
	Devices	under the appropriate category.	7-3.2
18.	Post Indicator	Annually: Verify a valve closure signal is received	NFPA 72;
	Valve (PIV)	within two full turns or one-fifth of the valve travel	Tables 7-2.2, 7-3.1, 8
		from the fully open position.	7-3.2
19.	Butterfly, gate,	Annually: Verify a valve closure signal is received	NFPA 72;
	and OS&Y valve	within two full turns or one-fifth of the valve travel	Tables 7-2.2, 7-3.1, 8
		from the fully open position.	7-3.2
20.	High/Low Tank	Annually: Functionally test the device and verify	NFPA 72;
	Level Switch	alarm indication is received.	Tables 7-2.2, 7-3.1, &
- 1	*** 1 /7		7-3.2
21.	High/Low	Annually: Functionally test the device and verify	NFPA 72;
	Temperature	alarm indication is received.	Tables 7-2.2, 7-3.1, 8
22	Switch	1 1 1 1 1 1 1 1 1 1	7-3.2
22.	High/Low	Annually: Functionally test the device and verify	NFPA 72;
	Pressure Switch	alarm indication is received.	Tables 7-2.2, 7-3.1, 8
23.	ALL	NEW/REPLACEMENT BATTERY: Conduct	NFPA 72,
		discharge test preferably at 1 or 2-hour discharge	Table 7-3.2
		rate. Using manufacturer's data, verify the battery	1 4010 7-3.2
		demonstrates at least 100% of rated capacity.	
	1	acinomistrates at reast 100% of rated capacity.	l

ESHQ	Document	TFC-ESHQ-FP-STD-04, REV A-5
	Page	6 of 20
FIRE PROTECTION SYSTEM TESTING, INSPECTION, AND	Effective Date	July 10, 2007
MAINTENANCE		

Table 1. Alarm System Testing/Inspection and Maintenance. (cont.)

	trol Panels	AU (EACD IDEAD) C1 1	NIEDA 70: TE-1-1
24.	Sealed Lead-	Annually: (FACP and RFAR)- Check open-	NFPA 72; Tables
	Acid	circuit voltage. Measure battery voltage under full-	7-2.2, 7-3.1, & 7-3.2
		load conditions with battery charger disconnected,	
		and direct current bells ringing. Clean all	
		connections. *Note: (May extend test up to 4years.	
		for specially designed high quality extended life	
		batteries based on manufacturer's recommendations	
		and results of previous capacity test.)	
		4 Years: (FACP and RFAR)- Replace batteries or	
		when testing indicates replacement is necessary.	
25.	Alarm Indicating	Annually: Actuate an initiating device to put the	NFPA 72; Tables
20.	Appliances:	system into alarm. Monitor the sound level	7-3.1 & 7-3.2
	rippinances.	produced by each audible device to ensure it is	7 3.1 & 7 3.2
	Supervised	clearly audible over the ambient background noise	
	Devices	level. Monitor each visual alarm to ensure it can be	
	Devices		
26	A 1 T., 4' 4'	seen clearly with normal ambient light levels.	NIEDA 70, T-1-1-
26.	Alarm Indicating	2 Months: Actuate an initiating device to put the	NFPA 72; Tables
	Appliances:	system into alarm. Monitor the sound level	7-3.1 & 7-3.2
		produced by each audible device to ensure it is	
	Unsupervised	clearly audible over the ambient background noise	
	Devices	level. Monitor each visual alarm to ensure it can be	
		seen clearly with normal ambient light levels. Once	
		per year this test is to be performed using FACP	
		backup power.	
27.	Annunciators	Annually: Send one device into the alarm	NFPA 72; Tables
		condition for each annunciator window. Verify the	7-2.2, 7-3.1, & 7-3.2
		alarm is received at the local annunciator.	
28.	Auxiliary	Annually: Functional test of all automatic initiation	NFPA 72; Tables
	Function	circuits to verify proper operation (e.g., door closer,	7-2.2, 7-3.1, & 7-3.2
	Circuits	HVAC shutdown, damper closure). See "fire	, ,
		dampers," item #1 in Section 2.6 for complete 2	
		year functional test.	
29.	Electro-Thermal	Annually: Verify operation of the initiating	NFPA 72; Tables
<i>∠ J</i> .	Links (ETLs)	circuitry by tripping the ETL or a simulation device	7-2.2, 7-3.1, & 7-3.2
	Links (ETLs)	in lieu of the ETL. Verify electrical continuity of	1-2.2, 1-3.1, & 1 - 3.2
		· · · · · · · · · · · · · · · · · · ·	
		the ETL using the manufacturer's instructions.	
Í		*10 Years: Electrically operate ETL, and verify it	
		trips the associated damper.	

ESHQ	Document	TFC-ESHQ-FP-STD-04, REV A-5
	Page	7 of 20
FIRE PROTECTION SYSTEM TESTING, INSPECTION, AND	Effective Date	July 10, 2007
MAINTENANCE		

Table 1. Alarm System Testing/Inspection and Maintenance. (cont.)

Control Panels

30.	Speakers (One-	Annually: Put the system into an operating mode.	NFPA 72; Tables
	Way Emergency	Monitor for voice, signal, tone, quality etc., as	7-3.1 & 7-3.2
	Voice/Alarm	appropriate. Monitor the sound level to ensure the	
	System)	alarm is clearly audible over the ambient	
		background noise level in all areas of the facility.	
31.	Communications	Weekly: Operate an emergency power source,	NFPA 1221;
	Centers and Fire	other than batteries, to supply the system for a	<u>11-4.1</u> 8-4.1
	Stations	continuous period of 1 hour.	
32.	Coded Radio	Annually: Perform a front button test on all RFAR	NFPA 72; Tables
	Reporting	panels. Examine and clean the boxes and test all	7-3.1 & 7-3.2
	Systems	functions. This test shall include the transmission of	
		a complete message function associated with each	
		box tested.	

ESHQ	Document	TFC-ESHQ-FP-STD-04, REV A-5
	Page	8 of 20
FIRE PROTECTION SYSTEM TESTING, INSPECTION, AND	Effective Date	July 10, 2007
MAINTENANCE		

Table 2. Suppression System Testing/Inspection and Maintenance.

'г	1.	Riser Flow Test	Annually: Conduct a main drain water flow test to	NFPA 25;
	1.	Kisel Flow Test	verify that the system is fully operable. Verify local	9-2.6 9-2.6
			water flow alarm functions.	y <u> </u>
			Quarterly: Conduct a main drain test on at least	
			one riser downstream of a backflow preventer or	
1	2	Caraca	pressure releasing device.	NEDA 25.
1	2.	Gauges	*Monthly: Check gauges to verify indicated	NFPA 25; 2-2.4 5.2.4
1			pressure is in the normal range.	2-2.4 3.2.4
			5 Years: Check all gauges with an inspector's	2-3.2 NFPA 25;
			gauge, or replace them with a new accurate gauge of	5.3.2
			the type, style, and range required for the	
			application.	
,	3.	Piping, etc.	2 Years: Visually inspect physical condition of	NFPA 25;
			piping, hangers and braces, alarm devices, hydraulic	2-2.2 <u>5.2.2</u>
			nameplate, sprinkler heads, and fittings.	
			510 Years: Examine internal condition of piping	10-2.2 NFPA 25;
			where conditions exist which could cause	13.2.2
'			obstructions.	
	4.	Sprinkler Heads	5 Years: For solder type sprinklers of extra high	NFPA 25;
			temperature class, test heads in accordance with the	<u>5.3.1.1.1.3</u>
			reference.	
			10 Years: For sprinklers installed on west systems	NFPA 25;
			for more than 50 years, test or replace heads in	2-3.1 5.3.1.1.1
			accordance with the reference.	2 3.1 5.3.1.1.1
			For fast response sprinklers in service for 20 years,	2-4.1.9 NFPA 25;
			test heads in accordance with the reference	<u>5.3.1.1.1.2</u>
			For anginklars on dry systems for 10 years, test or	NFPA 25;
			For sprinklers on dry systems for 10 years, test or replace heads in accordance with the reference.	5.3.1.1.5
			replace heads in accordance with the reference.	<u>5.5.1.1.1.5</u>
			Annually: Replace sprinkler heads for commercial	<u>NFPA 25</u>
			cooking equipment and for ventilation systems.	<u>5.4.1.9</u>
, [5.	Wet Systems	4 Months: Perform external riser inspection.	NFPA 25;
		(Alarm check		9-4.1 12.4.1.1
		valves & non-	5 Years: Conduct open faceplate inspection. Clean	NIEDA 25
		alarm valve	and inspect trim strainers and check valves, filters,	NFPA 25;
1		risers, i.e. "shotgun" risers)	and restriction orifices. Repair as necessary.	<u>12.4.1.2</u>
L		shorgun risers)		

ESHQ	Document	TFC-ESHQ-FP-STD-04, REV A-5
	Page	9 of 20
FIRE PROTECTION SYSTEM TESTING, INSPECTION, AND	Effective Date	July 10, 2007
MAINTENANCE		

 Table 2. Suppression System Testing/Inspection and Maintenance. (cont.)

ĺ	Supp	ression System		
	6.	Antifreeze Systems/ Winterization	Annually (Fall): Inspect all antifreeze systems each year before cold weather. Verify antifreeze solution meets NFPA 13 requirements.	NFPA 25; 2-3.4 <u>5.3.4</u>
			Drain sprinkler system drip lines, fire pump hose headers, drypipe sprinkler system air compressors, and dry system drum drip auxiliary drains.	
			*Inspect each facility by the end of October to ensure all areas are winterized to protect the installed fire protection systems. See TFC-BSM-FPM_PR-C-11, "Winterization Plan for 200 Area Tank Farm Facilities." Ensure the following (as a minimum):	
			a. Condition/operation and adequacy of heating systems, e.g. forced air, radiant heaters, portable heaters, etc.	
			b. Condition/operation of thermostats and filters.	
			c. Condition/operation/installation of heat tape systems.	
	7.	Deluge and Pre_action Systems	*Daily: (during cold weather if not provided w/low Temperature alarm) Inspect valve enclosure heating equipment to ensure at least 5°C (40°F) can be maintained. *Monthly: (during cold weather if provided w/low	NFPA 25; 9-4.312.4.3
			temp) Inspect valve enclosure heating equipment to ensure at least 5°C (40°F) can be maintained.	
			4 Months: Perform external riser inspection. Check and adjust priming water. Test air supervisory alarms.	
			Annually: Trip test the system with the control valve opened enough to cause the valve to latch in the open position. Test both the manual trip mechanism and automatic trip mechanism, where applicable. Visually inspect and clean interior during reset.	

ESHQ	Document	TFC-ESHQ-FP-STD-04, REV A-5
	Page	10 of 20
FIRE PROTECTION SYSTEM	Effective Date	July 10, 2007
TESTING, INSPECTION, AND		
MAINTENANCE		

 Table 2. Suppression System Testing/Inspection and Maintenance. (cont.)

Supp	oression System	Ta	
	Deluge and Pre-action Sections (2011)	3 Years: Trip test deluge valve under full flow conditions. Provide water diversion as required.	
	Systems (cont.)	5 Years: Visually inspect interior of deluge/preaction valves which can be reset without removing the faceplate. Inspect strainers, filters, orifices, and diaphragm chambers.	
8.	Dry Systems (Dry Valves,	*Daily: (during cold weather if not provided w/low temperature alarm)	NFPA 25; 9-4.4 <u>12.4.4</u>
	Accelerators, Exhausters)	*Monthly: (during cold weather if provided w/low temperature alarm) -Inspect valve enclosure heating equipment to ensure at least 5°C (40°F) can be maintained.	
		4 Months: Externally inspect the valve and trim. Inspect the priming water level to ensure that the proper water levels are being maintained as recommended by the dry valve manufacturer.	
		4 Months: Test high/low air pressure alarms on system to verify operation.	
		Annually (Spring or Summer): Triptest each dry-pipe valve, including quick opening device if installed, with the control valve partially open. Clean, inspect, and reset the valve. Inspect check valves and drip valves. Ensure water does not enter overhead piping.	
		3 Years: Trip test each dry-pipe valve with the control valve wide open, once every 3 years or when the system is altered. Verify/adjust set points on all switches, as necessary.	
		5 Years: Inspect strainers, filters, and restricted orifices.	
9.	Air Compressors Air Dryers	Annually: Check air dryers/desiccant in accordance with manufacturer's instructions.	NFPA 25; 2-4.25.4.2
		Perform maintenance on compressors in accordance with manufacturer's instructions.	

ESHQ	Document	TFC-ESHQ-FP-STD-04, REV A-5
	Page	11 of 20
FIRE PROTECTION SYSTEM	Effective Date	July 10, 2007
TESTING, INSPECTION, AND		
MAINTENANCE		

 Table 2. Suppression System Testing/Inspection and Maintenance. (cont.)

Dupp	ression bystem		
10.	Water Spray Fixed Systems	Annually: Sprinkler heads shall be inspected to verify spray pattern. Piping and hangers to be inspected.	NFPA 25; 7-3 7-4 10.2, 10.3
		Annually: The spray system shall be fully operated (including manual release device) to provide a system flush and verify water flow in accordance	
		with NFPA 25, 7–410.3. Nozzle strainers shall be cleaned after each flow/flush. Confirm drainage	
		area is not blocked or damaged.	
11.	Halon Systems	Semi-Annually: Check the agent quantity and pressure of refillable containers.	NFPA 12A; 4-1; 4-2; 4-3
		Visually inspect the total system.	
		Annually: Examine all system hoses for damage.	
		Thoroughly inspect and test system for proper	
		operation (including manual trip stations).	
		5 Years: Inspect all hoses for integrity, and subject	
		hoses to a pressure test. Visually inspect exterior of	
		container for integrity in accordance with the	
11.	Dry Chemical	Compressed Gas Association pamphlet C-6.	NFPA 17;
11.	Systems (Fixed)	*Monthly: Inspect system and components in accordance with manufacturer's instructions.	9-2; 9-3; 9-5
		Semi-Annually: Inspect and functionally test releasing devices and system operation in	
		accordance with manufacturer's instructions. (Do not discharge chemical agent.)	
		Annually: Replace fusible link temperature sensing devices.	
		12 Years: Hydrostatically test the chemical	
		container and hose assembly.	

ESHQ	Document	TFC-ESHQ-FP-STD-04, REV A-5
	Page	12 of 20
FIRE PROTECTION SYSTEM TESTING, INSPECTION, AND	Effective Date	July 10, 2007
MAINTENANCE		

 Table 2. Suppression System Testing/Inspection and Maintenance. (cont.)

Ι,	Dupp	ession bystem		
	12.	Control Valves	*Weekly: (valves without locks or tamper switches) Inspect the installation and verify control valves are in the open position.	NFPA 25; 9-312.3
			*Monthly: (valves with locks or tamper switches) Inspect the installation and verify control valves are in the open position.	
			Annually: Perform the following on each primary, sectional, and control valve:	
ļ			Oil or grease sprinkler system control valve stems.	
			Operate all valves the full travel of their mechanism to ensure they operate easily. Maintain a record of the number of turns required to operate each valve from the fully open to the fully shut position. Reopen the valve and check to see if the number of turns to close equals the number to open.	
			Open each PIV until spring or torsion is felt in the rod, indicating the rod <u>has not</u> become detached from the valve. Valves should be backed off one-quarter turn from wide open to prevent jamming.	
	13.	Check Valves	5 Years: Perform internal inspection. Repair as required.	NFPA 25; 9-4.2.112.4.2.1
	14.	Backflow Preventers	Annually: Flow the system at design flow rate. Measure friction loss across the preventer and compare with manufacturer's specifications maximum attainable flow rate (typically via the main drain).	NFPA 25; 9-6.2.212.6
	15.	Pressure Regulating Valves (sprinklers)	4 Months: Inspect condition and verify there are no leaks, and all hardware is in place.5 Years: Perform flow test, compare to previous	NFPA 25; 9-5 <u>12.5.1</u>
			test data and adjust device if necessary.	

ESHQ	Document	TFC-ESHQ-FP-STD-04, REV A-5
	Page	13 of 20
FIRE PROTECTION SYSTEM TESTING, INSPECTION, AND	Effective Date	July 10, 2007
MAINTENANCE		

 Table 2. Suppression System Testing/Inspection and Maintenance. (cont.)

Supp	oression System		
16.	Water Tanks	*Daily: (during cold weather)	NFPA 25;
		When the temperature of the environment that	6-2;
		surrounds the tank is 40°F or below, inspect the tank	6-3;
		level, the water temperature, and the heating system	6-4 9.2, 9.3
		to ensure it is operational and adequate to meet the conditions.	
		*Monthly: Inspect water level. Inspect air pressure in pressure tanks. Test cold temperature alarms.	
		*3 Months: Inspect support structure and general surroundings.	
		*Semi-Annually: Test water level alarm. Test each relief valve on pressure tanks.	
		*Annually: Inspect exterior conditions and expansion joints. Test heating systems and high water temperature limit switches. Maintain cathodic protection; cycle drain valves; and clean vents.	
		*3 Years: Inspect interior of steel tanks without cathodic protection and pressure tanks.	
		*5 Years: Inspect interior of tanks with cathodic protection. Test level gages.	
17.	Standpipes	2 Years: Inspect general condition of piping and	NFPA 25;
		appurtenances.	3-2;
			3-3 <u>6.1, 6.3</u>
		5 Years: Dry standpipe hydrostatic test.	

ESHQ	Document	TFC-ESHQ-FP-STD-04, REV A-5
	Page	14 of 20
FIRE PROTECTION SYSTEM TESTING, INSPECTION, AND	Effective Date	July 10, 2007
MAINTENANCE		

 Table 2. Suppression System Testing/Inspection and Maintenance. (cont.)

'г		Ilaaa and Ilaaa	*O	NIEDA 25.
1	18.	Hose and Hose Stations	*Quarterly: Inspect hose connections for general condition of components.	NFPA 25; 3-2.1; <u>Table 6.1</u>
		Stations	condition of components.	NFPA 1962;
			Annually: Inspect to ensure:	2-3.24.3.2
1			inspect to ensure.	2 3.2 113.2
			All equipment is in place and in good	
			condition.	
,				
l			Hose station valves are not leaking.	
ı			Hose racks or reels and nozzles are free	
			from mechanical damage.	
			from mechanical damage.	
			5 Years (initial); 3 Years (subsequent): Remove	
			and service-test hose stored on racks and reels and in	
			hose houses at intervals not exceeding 5 years after	
			installation and every 3 years afterwards.	
	19.	Fire Department	4 Months: Inspect and verify Fire Department	NFPA 25;
l		Connections	connections are accessible and free from	9-7.1 12.7.1
ıŀ	20.	Mainline	obstructions.	NIEDA 25.
	20.	Strainers	Annual: Flush-Clean strainer.	NFPA 25; 4-2
		Stramers	5 Years: Perform internal inspection of strainer.	4-4 12.4
<u> </u>	21.	Fire Hydrants	Annually: Cycle each ground valve over its full	NFPA 25;
		j	travel. Maintain a record of the number of turns for	4-4;
			both the open and close directions. Verify the	4-3;
			number of turns in each direction is the same.	9-3 <u>7.2, 7.3, 7.4</u>
			Annually: Lubricate and operate thread	
			mechanisms.	
			incentarisms.	
			Annually: Hydrant shall be opened fully and	
			flushed for at least one minute. Hydrant operation	
			and proper draining shall be verified.	
			5 Wasnes Classificational hardward to determine	
			5 Years: Flow test each hydrant to determine hydrant and distribution system flow characteristics.	
			Verify against known system performance.	
L			verify against known system performance.	

ESHQ	Document	TFC-ESHQ-FP-STD-04, REV A-5
	Page	15 of 20
FIRE PROTECTION SYSTEM TESTING, INSPECTION, AND	Effective Date	July 10, 2007
MAINTENANCE		

 Table 2. Suppression System Testing/Inspection and Maintenance. (cont.)

Sup	pression System		
22.	Fire Pumps	*Weekly: Test automatic starting on a pressure	NFPA 25;
		drop. Run 30 minutes minimum for diesel pumps,	5-2;
		10 minutes minimum for electric. Perform Table 8.1	5-3;
		shall be used to determine the minimum required	5-5
		<u>frequencies for inspection, testing, and maintenance</u>	9-5 8.2, 8.3, 8.5
		<u>frequencies</u> . All records shall be maintained on all	
		work performed.	
		s specified in Table 5.2.2 and record data specified	
		in reference Table 5-3.2.4.	
		XX : 6	
		Verify proper operation of circulation relief valves	
į l		and pressure relief valves.	
		*Annually: Conduct performance test of pump in	
		accordance with 5-3.38.3.3 of the reference.	
		accordance with 5-5.5 <u>6.5.5</u> of the reference.	
		Check controller timer.	
		- Check controller timer.	
		Check for proper indication of controller	
1		lights.	
		6	
		• Check all valves to make sure they are in the	
1		correct position (open or closed).	
		Pump performance test:	
,			
		• Verify pump speed at each flow.	
,			
		Record suction and discharge pressure at	
		each flow.	
,			
Į		Check water flow and alarm switches.	
		Toot making valve setting	
Į		Test relief valve setting.	
		Calibrate gages.	
1		- Canorate gages.	
		Operate speed trip (internal combustion)	
		operate speed trip (internal combustion)	
		*As Required: A preventive maintenance program	
		shall be established in accordance with the driver	
		and pump manufacturer's recommendation.	

ESHQ	Document	TFC-ESHQ-FP-STD-04, REV A-5
	Page	16 of 20
FIRE PROTECTION SYSTEM TESTING, INSPECTION, AND	Effective Date	July 10, 2007
MAINTENANCE		

Table 3. Miscellaneous System Testing/Inspection and Maintenance.

1.	Fire/Smoke	*4 Years: Carefully disconnect the actuating	NFPA 90A
	Dampers	device, and verify the damper closes without any	<u>5.4.7</u>
		additional force being required. Inspect the damper,	
		giving attention to hinges and other moving parts, to	
		see the damper is in good operable condition. Check the latch, if provided, and lubricate moving	
		parts, if necessary.	
		Dampers listed for "dynamic air flow" shall be	
		tested under air flow conditions only if the system is designed for dynamic flow operation of the damper.	
		designed for dynamic flow operation of the damper.	
		Verify the damper force will totally close and latch	
		the damper under normal operating conditions.	
2.	Fire and Smoke	*2 Years: Inspect all fire and smoke barriers within	NFPA 90A;
	Barriers	the building or facility to ensure they are capable of	App. B
		providing the necessary control of smoke or fire	
		(i.e., have not been penetrated, seals in acceptable	
		condition). Any questionable findings shall be resolved with approval of the area fire protection	
		engineer.	
3.	Fire Doors	*Annually: Examine hardware and replace any	NFPA 80; Ch.15
		parts found to be inoperative. Inspect Tinclad and	<u>5.2.1</u>
		Kalamein doors for dry rot. Inspect chains or cables	
		used on suspended doors for excessive wear and stretching.	
		stretching.	
		Check chains or cables on counter-balanced doors,	
		and make adjustments to ensure proper latching and	
		to keep the doors in proper relation to the opening.	
		Keep guides and bearings well-lubricated to	
		facilitate operation. Keep self-closing devices in proper working condition at all times. Test doors	
		normally held in the open position and equipped	
		with automatic closing devices to ensure proper	
		operation. Test all doors for proper operation and	
		full closure.	

ESHQ	Document	TFC-ESHQ-FP-STD-04, REV A-5
	Page	17 of 20
FIRE PROTECTION SYSTEM	Effective Date	July 10, 2007
TESTING, INSPECTION, AND		- · ·
MAINTENANCE		

Table 3. Miscellaneous System Testing/Inspection and Maintenance. (cont.)

4.	Ventilation	*Annually: (Increase frequency if necessary. Does not apply to radiological contaminated ducts.)	NFPA 90A; App. B
		For building ventilation, exhaust, blower and duct systems where flammable/combustible vapors, residues, lint, and/or fibers may accumulate, perform, as a minimum, a documented inspection with cleaning, calibration, and replacement of components as required. Ensure the following:	
		grill plates are clean	
		Replace filter media (if design permits)	
		Remove any buildup of foreign material from the duct interior, if conditions warrant.	
		NOTE: The extent of inspection and maintenance necessary depends on many factors, including the environment being ventilated, material exhausted, equipment type, and operating pattern. All components exposed to the airflow should be included in the inspections. Combustible dust buildup (thick enough to obscure the surface of the duct) is a hazard. Similarly, exhaust systems for areas where combustible liquids are used (such as lubricants and solvents) can be coated with a highly combustible finish and be a hazard.	NED 4 40
5.	Portable Fire Extinguishers	*Monthly: Inspect each extinguisher for:	NFPA 10; 4-3.1 <u>7.2.2</u>
	(All)	Proper location	
		• Accessibility	
		Seals not broken	
		Pressure gage in operable range (if provided)	

ESHQ	Document	TFC-ESHQ-FP-STD-04, REV A-5
	Page	18 of 20
FIRE PROTECTION SYSTEM TESTING, INSPECTION, AND	Effective Date	July 10, 2007
MAINTENANCE		

 Table 3. Miscellaneous System Testing/Inspection and Maintenance. (cont.)

Portable Fire Extinguishers (cont.) Fullness by "hefting" (for extinguishers without a gauge.)	fting" (for extinguishers	Dortoble Fire
	.)	
Physical condition	on	•
NOTES:		
1. Facility personnel are responsible for initialing the inspection tag during the monthly inspection. If facility personnel install new tags on the extinguishers, they must transfer the extinguisher data from the top of the old tag to the new tag.	spection tag during the ion. If facility personnel on the extinguishers, they e extinguisher data from the	
2. An electronic bar-coding system or manual log may be used for recording the monthly inspection in lieu of the inspection tag. The records shall be maintained current and available at all times for inspection.	I for recording the monthly u of the inspection tag. The maintained current and	
The HFD annual inspection does not replace the facility monthly inspection.		
Dry chemical extinguishers Annually: Non-stored pressure extinguishers: Inspect for unimpaired physical condition, perform internal inspection, pressure gage in operable range, and ensure dry chemical not compacted. Perform internal inspection on non-stored pressure extinguishers.	bhysical condition, perform sure gage in operable range, not compacted. Perform	extinguishers I i a
Stored pressure extinguishers: Inspect for unimpaired physical condition, verify and pressure gage in operable range, and. Wweigh extinguishers. Stored pressure extinguishers: Inspect for unimpaired physical condition, verify and pressure gage in operable range, and weigh extinguishers.	ndition <u>, verify</u> and pressure <u>NFPA 10;</u>	u g
Carbon Dioxide & Pressurized Water *5 Years: Hydrostatically test and perform maintenance *5 Years: Hydrostatically test and perform 5-27.3.1.1		& Pressurized r
Stored Pressure (having a 12yr. Hydrostatic test) *6 Years: Disassemble and perform maintenance on units *6 Years: Disassemble and perform maintenance on units		Stored Pressure (having a 12yr.
Non-rechargeable Extinguishers *12 Years: Remove from service. NFPA 10: 4-4.17.3.1.2		rechargeable

ESHQ	Document	TFC-ESHQ-FP-STD-04, REV A-5
	Page	19 of 20
FIRE PROTECTION SYSTEM	Effective Date	July 10, 2007
TESTING, INSPECTION, AND		
MAINTENANCE		

Table 3. Miscellaneous System Testing/Inspection and Maintenance. (cont.)

	Halon, dDry chemical, and stored pressure extinguishers (not including pressurized water and CO ₂ .)	*12 Years: Hydrostatically Test	NFPA 10 5-27.3.1.2
6.	Exit Signs	*Monthly: Inspect exit signs with internal electrical lighting source to ensure all lamps are functional. *Annually: Inspect tritium gas-powered exit signs to ensure the tritium gas tubes are not damaged, the signs are in place and are not obstructed. Replace the signs before their expiration date as noted on the individual signs. *Annually: Exit signs equipped with standby batteries shall be operationally tested for a minimum of 1-1/2 hours.	NFPA 101; 7.10.9.1
7.	Building Emergency Lights	 *Monthly: Operationally test lights for a minimum of 30 seconds. During this test, it is suggested the following items be verified also: Lamps are not cracked or damaged Units are securely mounted Lamps are properly positioned to provide illumination for the required areas Lamps illuminate within 10 seconds of switching to the backup power supply. *Annually: Operationally test lights for a minimum of 1-1/2 hours. NOTE: When emergency generators are used to satisfy the emergency light requirements, the generators/systems shall be tested per NFPA 110, "Standard for Emergency and Standby Power Systems." The items above do not apply. 	NFPA 101; 7.9.3

ESHQ
FIRE PROTECTION SYSTEM
TESTING, INSPECTION, AND
MAINTENANCE

ECHO

Document
Page
Effective Date

TFC-ESHQ-FP-STD-04, REV A-5 20 of 20 July 10, 2007

ATTACHMENT A - RECALL FREQUENCY PROTOCOL

Recurring frequencies expressed in this standard are to be applied using the following criteria.

- a. Test frequencies may be extended by a 25% grace period on a case-by-case-basis to accommodate operational/scheduling conflicts when coordinated between, and agreed to, by the facility and the Hanford Fire Marshal.
- b. Specific calendar dates are not to be used for determining the next scheduled due date nor late date. Any activity performed within the specified frequency (e.g., monthly, annually, semiannually) complies with the requirements established by this standard.
- c. Inspection, test, and maintenance activities with frequencies longer than a month shall be scheduled to occur during the last month of the frequency specified for the given activity within this standard. The activity shall not be considered delinquent until the first day of the month following the scheduled month. For example, if an annual activity is originally to be performed in January, it shall next be scheduled for performance during January of the following year and shall comply with these criteria if performed on or before January 31.
- d. Scheduling of these activities that are performed late, whether delinquent or as permitted by the 25% grace period, shall continue to be scheduled using the original by-month sequence. For example, an annual activity scheduled for March but actually performed in June shall next be scheduled for performance the following March. Likewise, an annual activity scheduled for performance in August but performed in July would continue to be scheduled for performance during August of subsequent years.